

Alfa 164

Powertrain

Systemem	Ident.	DTC	FrFrame	Livedata	Actuators	Coding
Transmissie						
ZF 4HP18 K	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	94	20	0	<input type="checkbox"/>
Injectie Unit (Motor ECU)						
Bosch Motronic M1.7	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	118	24	0	<input type="checkbox"/>
Bosch Motronic M1.7 3.0l V6	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	82	24	0	<input type="checkbox"/>
Bosch Motronic M1.7 IMMO	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	130	26	0	<input type="checkbox"/>
Bosch Motronic M3.7.1 (3.0l 24v 4X4)	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	169	34	0	<input type="checkbox"/>
Bosch Motronic ML4.1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	141	25	0	<input type="checkbox"/>

Chassis

Systemem	Ident.	DTC	FrFrame	Livedata	Actuators	Coding
ABS/ESP Systemem						
Bosch 5.3	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	4	8	8	<input type="checkbox"/>

DTC = Diagnostic Trouble Codes = Foutcodes lezen en wissen