

AutoMaker:Seat
Version:V5.00

NOTES:

- ✓ This function is supported.
 - This function is not supported.
 - ※ This function may be supported, which depends on the actual condition of the vehicle.
 - ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

NOTE:

The coverage includes all models from 1996 to 2014.

Control Unit	ECU Info	Read Codes	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function(✓)	Special Function(※)
ABS Brakes	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004, 0005	0006, 0007, 0008, 0009, 000C
Auto Dist. Reg	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004, 0005	0006, 0007, 0009
Engine	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004 0005 0008	0006, 0007, 0009
Auto Trans	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Auto HVAC	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Cent. Elect.	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Park/Steer Assist	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Airbags	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Steering wheel	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Instruments	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004 0005	0006, 0007, 0009, 000A
Aux. Heat	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004 0005	0006, 0007, 0009
CAN Gateway	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Engine II	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Engine III	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004 0005	0006, 0007, 0009
AWD	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Immobilizer	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Centr. Locks	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Navigation	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Inter. Monitor	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Central Conv.	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Xenon Range	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Radio	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Engine Conjunct.	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Diesel pump	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Electric drive	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Battery Regul.	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Battery charger	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Clutch	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Differential Locks	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Door Elect, Driver	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Door Elect, Pass.	✓	✓	✓	✓	※	✓	0001, 0002, 0003, 004 0005	0006, 0007, 0009

Door, Rear Left	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Door, Rear Right	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Braker Booster	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Braker Boost. Assi.	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Parking Brake	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009, 000B
Entry Assist, Driver	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Entry Assist, Passenger	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Steering Angle	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009, 000C
Susp. Elect.	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Anti Slip	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Level Control	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Steering assistance	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Rear spoiler	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Stabilizers	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Chassis Control	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Acc/Start Auth.	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Tire pressure monitoring	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Telematics	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Seat Mem. Pass	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Auto Roof	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Seat Mem. Driver	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Seat, Rear PS	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Parking aid	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Control Head	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Sound system	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
TV-Tuner	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Voice Control	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Telephone	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
HVAC, Rear	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Roof Electronics	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Seat, Rear, DS	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Auxiliary Fuel Tank	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Wiper Electr.	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Left light control	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Right light control	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Auto. Lighting switch	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Towing Protection	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Trailer Function	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Sec. Air Heating	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Active Steering	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0008, 0009
Position Sensing	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009

Lane Change	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Tire Pressure II	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Lane Maintain	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Back-up Cam.	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Sliding Door Left	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Driver Ident.	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Intercom	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Special Function	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Data Transfer	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Operations	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Trunk Elect.	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Auxiliary Heater	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Media Player 1	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Media Player 2	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Media Player 3	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Media Player 4	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Ctrl Head RR	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Ctrl Head LR	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Ctrl Head Roof	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Ctrl Head Dash	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Digital Radio	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Digital TV	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Centr. Electr. II	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Information Electr.	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Centr. Conv. II	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009
Inform. Electr. II	√	√	√	√	※	√	0001, 0002, 0003, 004 0005	0006, 0007, 0009

Special Function

Index	Specil Function Name	Index	Special Function Name
0001	Coding	0002	Basic Settings
0003	Adaptation	0004	Security Access
0005	AdvancedDataStream	0006	Single Reading
0007	Login CodingII	0008	Readiness
0009	Advanced ID	000A	OilReset
000B	EPB	000C	Steering
000D	Read login password		