

AutoMaker:Abarth
Version:V7.00

NOTES:

- ✓ This function is supported.
 - This function is not supported.
 - ※ This function may be supported, which depends on the actual condition of the vehicle.
 - ✓ This function is the new feature in this version.
- As for special function please refer to the special function table.

Model	Version	System	Ecu info	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
500	1.4 TURBO 16V	Litronic discharge headlamp (left)	✓	✓	✓	✓	✓	○
500	1.4 TURBO 16V	Litronic discharge headlamp (right)	✓	✓	✓	✓	○	○
500	1.4 TURBO 16V	Marelli/Microsoft Convergence (EP)	✓	✓	✓	✓	✓	0091 0090
500	1.4 TURBO 16V	Bosch ABS 8 ESP (EP)	✓	✓	✓	✓	✓	0034 0001
500	1.4 TURBO 16V	Denso Heater (EP)	✓	✓	✓	✓	✓	○
500	1.4 TURBO 16V	DELPHI (EP) 2 Power Steering	✓	✓	✓	✓	○	0054
500	1.4 TURBO 16V	Marelli/Microsoft C3 (EP) Convergence	✓	✓	✓	✓	✓	0091 0090
500	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP eng. 1.4)	✓	✓	✓	✓	✓	0031 00C1
500	1.4 TURBO 16V	SIEMENS Airbag (EP-Proxi)	✓	✓	✓	✓	✓	○
500	1.4 TURBO 16V	DENSO Single-zone climate control (EP)	✓	✓	✓	✓	✓	0053
500	1.4 TURBO 16V	VALEO Parking Control unit (EP) 2	✓	✓	✓	✓	○	004C 0049
500	1.4 TURBO 16V	MARELLI Instrument panel (EP) 2	✓	✓	✓	✓	✓	0007 005D 0006 0044 0045 0059 004D
500	1.4 TURBO 16V	DELPHI Body Computer (EP) 2	✓	✓	✓	✓	✓	○
500	1.4 TURBO 16V	Lauberhorn Convergence (EP)	✓	✓	✓	✓	✓	0091 0090
500	1.4 TURBO 16V	CONTINENTAL Airbag (EP)	✓	✓	✓	✓	✓	○
500	1.4 TURBO 16V	Marelli SELESPEED CFC319 Automatic Gearbox (EP)	✓	✓	✓	✓	✓	0097 0019 0096 00C2 003A 003F 00A2 003C 00D4 0041 00D0 00CA
500	1.4 TURBO 16V	DENSO one-zone climate control system PTC (EP)	✓	✓	✓	✓	✓	0053
500	1.4 TURBO 16V	Bosch Motronic Injection Me17.3.0 CF6/E0BD (1.4 eng.)	✓	✓	✓	✓	✓	0031 00DE 007E 0037 0036 00A0
500	1.4 TURBO 16V	Marelli TFT instrument panel	✓	✓	✓	✓	✓	0006 0044 0045 005D 0059
500	1.4 TURBO 16V	Marelli SELESPEED CFC319 CF6 (EP) automatic transmission	✓	✓	✓	✓	○	003F 00CE 0019 0096 00C2 0097 003A 003C 00D4 0041 00D0 00CA
GRANDE PUNTO	1.4 TURBO 16V	Marelli/Microsoft Convergence (EP)	✓	✓	✓	✓	✓	0091 0090
GRANDE PUNTO	1.4 TURBO 16V	Marelli cluster (EP)	✓	✓	✓	✓	✓	0007 005D 0006 0044 0045 0059
GRANDE PUNTO	1.4 TURBO 16V	TRW Airbag (EP-Proxi)	✓	✓	✓	✓	✓	○
GRANDE PUNTO	1.4 TURBO 16V	Bosch ABS 8 ESP (EP)	✓	✓	✓	✓	✓	0034 0001
GRANDE PUNTO	1.4 TURBO 16V	Denso Climate Control (EP)	✓	✓	✓	✓	✓	0053
GRANDE PUNTO	1.4 TURBO 16V	Denso Heater (EP)	✓	✓	✓	✓	✓	○
GRANDE PUNTO	1.4 TURBO 16V	TRW Tyre Pressure Control (EP)	✓	✓	✓	✓	✓	008B 004A 0008 008C 008D 0093 000C 0019
GRANDE PUNTO	1.4 TURBO 16V	Delphi Body Computer (EP)	✓	✓	✓	✓	✓	○
GRANDE PUNTO	1.4 TURBO 16V	DELPHI (EP) 2 Power Steering	✓	✓	✓	✓	○	0054
GRANDE PUNTO	1.4 TURBO 16V	Marelli/Microsoft C3 (EP) Convergence	✓	✓	✓	✓	✓	0091 0090

GRANDE PUNTO	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP eng. 1.4)	✓	✓	✓	✓	✓	0031 00C1
GRANDE PUNTO	1.4 TURBO 16V	VALEO Parking Control unit (EP) 2	✓	✓	✓	✓	○	004C 0049
GRANDE PUNTO	1.4 TURBO 16V	Delphi (EP) 3 Body computer	✓	✓	✓	✓	✓	○
GRANDE PUNTO	1.4 TURBO 16V	DELPHI (EP) 3 Electric Steering	✓	✓	✓	✓	○	0054
GRANDE PUNTO	1.4 TURBO 16V	Bosch ABS 8 ESP (EP) 2	✓	✓	✓	✓	✓	0034 0001
GRANDE PUNTO	1.4 TURBO 16V	CONTINENTAL Airbag (EP-Proxy) 2	✓	✓	✓	✓	✓	○
GRANDE PUNTO	1.4 TURBO 16V	Marelli instrument cluster (EP) 3	✓	✓	✓	✓	✓	0007 005D 0006 0044 0045 0059
GRANDE PUNTO	1.4 TURBO 16V	Lauberhorn Convergence (EP)	✓	✓	✓	✓	✓	0091 0090
GRANDE PUNTO	1.4 TURBO 16V	Delphi Body computer (EP) 4	✓	✓	✓	✓	✓	○
GRANDE PUNTO	1.4 TURBO 16V	CONTINENTAL Airbag (EP)	✓	✓	✓	✓	✓	○
PUNTO EVO	1.4 TURBO 16V M.AIR	Marelli/Microsoft Convergence (EP)	✓	✓	✓	✓	✓	0091 0090
PUNTO EVO	1.4 TURBO 16V M.AIR	Denso Heater (EP)	✓	✓	✓	✓	✓	○
PUNTO EVO	1.4 TURBO 16V M.AIR	TRW Tyre Pressure Control (EP)	✓	✓	✓	✓	✓	008B 004A 0008 008C 008D 0093 000C 0019
PUNTO EVO	1.4 TURBO 16V M.AIR	Marelli/Microsoft C3 (EP) Convergence	✓	✓	✓	✓	✓	0091 0090
PUNTO EVO	1.4 TURBO 16V M.AIR	VALEO Parking Control unit (EP) 2	✓	✓	✓	✓	○	004C 0049
PUNTO EVO	1.4 TURBO 16V M.AIR	DELPHI (EP) 3 Electric Steering	✓	✓	✓	✓	○	0054
PUNTO EVO	1.4 TURBO 16V M.AIR	Bosch ABS 8 ESP (EP) 2	✓	✓	✓	✓	✓	0034 0001
PUNTO EVO	1.4 TURBO 16V M.AIR	Marelli instrument cluster (EP) 3	✓	✓	✓	✓	✓	0007 005D 0006 0044 0045 0059
PUNTO EVO	1.4 TURBO 16V M.AIR	Magneti Marelli Injection IAW 8GMF CF5/E0BD (EP eng. 1.4)	✓	✓	✓	✓	✓	0028 00BF 0092 00C0 00B8 0031 00C1 00BE
PUNTO EVO	1.4 TURBO 16V M.AIR	Lauberhorn Convergence (EP)	✓	✓	✓	✓	✓	0091 0090
PUNTO EVO	1.4 TURBO 16V M.AIR	Delphi Body computer (EP) 4	✓	✓	✓	✓	✓	○
PUNTO EVO	1.4 TURBO 16V M.AIR	Denso 2 Single-zone climate control (EP)	✓	✓	✓	✓	✓	0053
PUNTO EVO	1.4 TURBO 16V M.AIR	CONTINENTAL Airbag (EP)	✓	✓	✓	✓	✓	○
PUNTO EVO	1.4 TURBO 16V M.AIR	ABS Bosch 9 ESP (EP) 2	✓	✓	✓	✓	✓	0001 00C7 00DC 0030
500	2012	GearboxPTS (EP)	✓	✓	✓	○	○	
500	2012	IPC	✓	✓	✓	✓	✓	
500	2012	VTM	✓	✓	✓	✓	○	
500	2012	CTM	✓	✓	✓	✓	✓	
500	2012	EPS	✓	✓	✓	✓	○	
500	2012	TCM	✓	✓	✓	✓	✓	
500	2012	ABS	✓	✓	✓	✓	✓	
500	2012	BCM	✓	✓	✓	✓	✓	
500	2012	RADIO	✓	✓	✓	✓	○	
500	2012	HVAC	✓	✓	✓	✓	✓	
500	2012	TPM	✓	✓	✓	✓	✓	
500	2012	ORC	✓	✓	✓	✓	○	
500	2012	PCM	✓	✓	✓	✓	✓	
500	2013	TCM	✓	✓	✓	✓	✓	
500	2013	HVAC	✓	✓	✓	✓	✓	
500	2013	EPS	✓	✓	✓	✓	○	
500	2013	CTM	✓	✓	✓	✓	✓	
500	2013	TPM	✓	✓	✓	✓	✓	
500	2013	ABS	✓	✓	✓	✓	✓	

500	2013	PTS	√	√	√	○	○	
500	2013	RADIO	√	√	√	√	○	
500	2013	IPC	√	√	√	√	√	
500	2013	VTM	√	√	√	√	○	
500	2013	BCM	√	√	√	√	√	
500	2013	ORC	√	√	√	√	○	
500	2013	PCM	√	√	√	√	√	
500	2014	VTM	√	√	√	√	○	
500	2014	EPS	√	√	√	√	○	
500	2014	CTM	√	√	√	√	√	
500	2014	TCM	√	√	√	√	√	
500	2014	BCM	√	√	√	√	√	
500	2014	ORC	√	√	√	√	○	
500	2014	TPM	√	√	√	√	√	
500	2014	IPC	√	√	√	√	√	
500	2014	PCM	√	√	√	√	√	
500	2014	ABS	√	√	√	√	√	
500	2014	HVAC	√	√	√	√	√	
500	2014	PTS	√	√	√	○	○	
500	2014	RADIO	√	√	√	√	○	

Special Function

Index	Specil Function Name	Index	Specil Function Name
0001	Static test	0071	Replacement of injector cyl. 1
0002	Homologation number	0072	Replacement of injector cyl. 2
0003	System configuration	0073	Replacement of injector cyl. 3
0004	Inputs status	0074	Replacement of injector cyl. 4
0005	Throttle learn storage	0075	Replacment of control unit and injector/s
0006	Reset odometer	0076	Replacement of Lambda sensor
0007	Headlamp pos. correct.	0077	Zeroing fan mode learn
0008	Wheel transmitters learning	0078	Replacement Lambda sensor
0009	Looks for faulty wheel transmitter	0079	Replacement injector cyl. 5
000A	Automatic Configuration Read	007A	Replacement injectors (4 cyl. bank)
000B	Automatic Configuration Write	007B	Air/Fuel learn setting
000C	Manual System Configuration	007C	Engine - Control Unit Group Replacement
000D	System calibration	007D	Servo Mechanism Group Replacement
000E	Lambda sensor check	007E	Speed limit setting
000F	Part. Filter regeneration	007F	Borg Warner sol. valves compatibility
0010	FAP Temperature Probe presence configuration	0080	Self-adapting parameters zeroing (air)
0011	Air flow sensor replacement	0081	Self-adapting parameters zeroing (knock)
0012	Rail pressure sensor replacement	0082	Particulate filter replacement (only for version with DPF)
0013	Rail pressure sensor and injector/s replacement	0083	Differential pressure sensor replacement (only for version with DPF)
0014	Injector replacement (per bank)	0084	Pre-catalyser replacement (only for version with DPF)
0015	Replacement of the additive, or the pump, or the tubes.	0085	Particulate filter regeneration (only for version with DPF)
0016	System configuration via MaxiSys Web	0086	Air flow meter replacement (only for version with Lambda sensor)
0017	Mounting check	0087	Lambda sensor replacement (only for version with Lambda sensor)
0018	Wheel identification check	0088	Cruise Control Learn
0019	Control unit replacement	0089	Air conditioner Learn
001A	Pressure sensor calibration	008A	Gearbox Lever Position Learn
001B	Injector codes read	008B	Antenna replacement
001C	FAP Replacement	008C	Control unit activation
001D	Additive type configuration	008D	Control unit deactivation
001E	RH distribution flap learn	008E	Deletion stored buttons
001F	LH distribution flap learn	008F	Oil change (only for version with DPF)
0020	LH mixing flap learn	0090	Audio System Test
0021	RH mixing flap learn	0091	Convergence System Restart
0022	Engine type configuration	0092	Phonic wheel replacement
0023	Chronotachigraph Control Unit (CCT)	0093	Alarm state check
0024	LED colours configuration	0094	High pressure pump replacement
0025	Accelerometer calibration	0095	Additional diesel circuit filling
0026	Clutch pedal learning	0096	Gearbox replacement
0027	Startup with Code Card	0097	Gearbox oil accumulator replacement
0028	Oil change	0098	Pilot injection learn
0029	Steering angle calibration	0099	Air flow meter sensor replacement
002A	Phonic wheel learn	009A	ECO switch replacement
002B	Speed limit	009B	End of line self-calibration
002C	Injector classification	009C	Forced trim correction
002D	Brake bleed	009D	Phase sensor learn zeroing
002E	EGR valve learn	009E	Vehicle geometry height setting

002F	Fuel supply system	009F	Pneumatic circuit filling
0030	Recognition of speed sensor type	00A0	Overboost counter reset
0031	Neutral signal learn	00A1	Cam edges zeroing (VVT)
0032	Fuel supply manifold bleed	00A2	Longitudinal acceleration signal learn
0033	Replacement of pressure/temperature sensor in methane rail	00A3	JukeBox data deletion
0034	Longit. acc. sensor calibration	00A4	Secondary wheel identification deletion
0035	Self-adaptation Parameter erasure	00A5	ECO/SPORT switch replacement
0036	Zeroing of self-adaption parameters	00A6	EGR valve replacement
0037	Self-learnt functions reset	00A7	Variable geometry turbo replacement
0038	Dist. To Next Service Zeroing (Coupon)	00A8	'UP Function' switch replacement
0039	Call buttons configuration	00A9	Automatic gearbox replacement
003A	Clutch replacement	00AA	Automatic gearbox and Control unit replacement
003B	KIT/Gearbox replacement	00AB	Automatic gearbox oil replacement
003C	Electropump replacement	00AC	Replacement of particulate filter with built-in pre-catalyzer (only for versions with DPF)
003D	Statistical data deletion	00AD	Services Interval KM message
003E	Tunnel lever replacement	00AE	Knock counter reset
003F	Steering wheel levers replacement	00AF	Parking manoeuvre status
0040	KIT/Pump replacement	00B0	Differential pressure sensor replacement
0041	Pump relay replacement	00B1	Particulate filter with integrated pre-cat replacement
0042	AUTO switch replacement	00B2	Particulate filter regeneration
0043	Vehicle configuration deletion	00B3	Resetting distance travelled with Water Temp. w. lamp ON
0044	Seat belts alarm exclusion	00B4	Resetting distance travelled with Water in diesel w. lamp ON
0045	Seat belts alarm Enable	00B5	Replacement injector/s
0046	Vehicle type learn reset	00B6	Levers on steering wheel learn
0047	System Configuration Read	00B7	UniAir module replacement
0048	System Configuration Write	00B8	Supercharging system components replacement
0049	Tow hook presence enable	00B9	Downstream lambda sensor and/or catalyzer and/or Injectors replacement
004A	Alarm deletion	00BA	Pre-catalyzer replacement
004B	Reset self-adapt. param. and idle act.	00BB	Motorised throttle replacement
004C	Tow hook presence disable	00BC	Particulate filter replacement
004D	Instrument panel lighting	00BD	MultiAir Rolling finger replacement
004E	Clutch bleed	00BE	Rpm sensor and/or distribution belt replacement
004F	Accumulator depressurisation	00BF	Oil temperature sensor replacement
0050	Clutch self-calibration enable	00C0	Timing sensor and/or cam replacement
0051	End of line / service self-calibration	00C1	Performance limiting deactivation
0052	New actuators	00C2	Hydraulic Kit replacement
0053	Flap actuators learning test	00C3	Replacement of variable geometry turbo and/or turbo posit. sensor
0054	Position sensor calibration	00C4	Replacement of lambda sensor and/or spark plugs and/or injectors
0055	Odometer write	00C5	Mechanical waste-gate valve replacement
0056	Oil Counter Write	00C6	Phonic wheel and/or phase sensor and/or rev sensor replacement
0057	Inspection service value	00C7	Lateral and longitud. acceleration sensor calibration
0058	Oil change servicing information delete	00C8	Load valves calibration
0059	Instrument panel replacement	00C9	Pilot valves calibration
005A	Phonic wheel learn reset	00CA	Sensors module replacement
005B	Engagement lever pin securing screw diagnosis	00CB	Electropump drive unit replacement
005C	Selection lever return diagnosis	00CC	Odd no. gear clutch position sensor replacement
005D	Servicing information delete	00CD	Even no. gear clutch pressure sensor replacement

005E	Memory mode write	00CE	Longitudinal acceleration sensor replacement
005F	Control Unit Unlock	00CF	Odd and/or even gear clutch replacement
0060	Calculation of clutch degradation index	00D0	Selection and/or engagement clutch electrovalve replacement
0061	Steering angle reset	00D1	Gearbox and hydraulic KIT replacement
0062	Test limit speed disable	00D2	Alcohol fuel setting
0063	Test limit speed restore	00D3	Petrol fuel setting
0064	VIN Code Configuration	00D4	Gearbox button panel replacement
0065	Personal data deletion	00D5	Air flow meter replacement
0066	Cyl. 1 injector classification	00D6	Air metering unit replacement
0067	Cyl. 2 injector classification	00D7	Supercharg. air cooling SV replacement
0068	Cyl. 3 injector classification	00D8	Knock sensor and/or spark plug replacement
0069	Cyl. 4 injector classification	00D9	Lambda sensor and/or catalytic convertor and/or injector replacement
006A	Cyl. 5 injector classification	00DA	Intelligent alternator (IAM) replacement
006B	Injector classification (4 cyl. bank)	00DB	Rpm sensor and/or timing chain replacement
006C	Injector classification (5 cyl. bank)	00DC	Longitudinal/lateral Accel. sens. calibration reset
006D	Deletion of statistical data relating to errors	00DD	Sensor replacement
006E	CITY switch replacement	00DE	Replacement of potentiometer and/or clutch group
006F	SPORT switch replacement	00DF	Fuel supply system component replacement
0070	Cruise control learn zeroing	00E0	Fuel pressure regulator replacement (high pressure pump input)