

Fiat Seicento

Powertrain

Systemem	Ident.	DTC	FrFrame	Livedata	Actuators	Coding
Accu bewaking						
Procond	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0	22	0	<input type="checkbox"/>
Automatische koppeling						
Valeo	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	26	0	0	<input type="checkbox"/>
Injectie Unit (Motor ECU)						
Magneti-Marelli IAW 4AF/4EF/59F/5AF	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	22	73	17	<input checked="" type="checkbox"/>
Injectie unit Magneti-Marelli IAW						
IAW 16F	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0	23	0	<input type="checkbox"/>

Chassis

Systemem	Ident.	DTC	FrFrame	Livedata	Actuators	Coding
ABS/ESP Systemem						
Bosch 5.3	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	4	8	8	<input type="checkbox"/>
Electronische sturbekrachtiging						
NSK (electro motor)	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	21	6	0	<input type="checkbox"/>
NSK (intern. verbr. motor)	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	24	8	0	<input type="checkbox"/>
Tractie controle						
Siemens V.M.U.	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	17	1	0	<input type="checkbox"/>

Body

Systemem	Ident.	DTC	FrFrame	Livedata	Actuators	Coding

Rollende Code	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	16	7	0	<input checked="" type="checkbox"/>
Airbag						
TRW MY 1997	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	2	22	0	<input type="checkbox"/>
Acculader						
Siemens	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	31	0	0	<input type="checkbox"/>

DTC = Diagnostic Trouble Codes = Foutcodes lezen en wissen